

3M™ Drive-Thru Headset G5

Quick Start Guide



▶ Buttons

- Volume**
Adjust Volume Level
- Lane 2**
Answer Lane 2 Order Point in Dual Lane
- Paging**
Talk to Other Headsets
- Lane 1**
Answer Lane 1 Order Point in Dual Lane

- **Feather-touch buttons** sense finger pad for a touch versus push
- Vibration confirms that the button has been pressed

NOTE: In a Single Lane operation, use Lane 1 or Lane 2 touch zones to answer the Order Point.

▶ Light on Microphone Boom



- **Green (Steady) Light:** Lane 1 no car present, stand by
- **Red/Green (Steady) Light:** Lane 2 (Dual Lane) no car present, stand by
- **Blue (Flashing) Light:** Vehicle arrived, but not answered
- **Blue (Steady) Light:** Vehicle present and answered
- **Red (Steady) Light:** Talk (either lane or page)



▶ Headset Charging Station and Batteries

Headset Charging Station
Charge headsets without removing batteries



Battery
Four lights indicate 100% fully charged



▶ Battery Removal



1. Place pointer finger between Control Pod and battery; place thumb under the battery latch.

2. Using a pinching motion, pinch and gently pull battery straight out.

**Contact your
3M Representative
Today**

1-800-328-0033
3M.com/G5



Commercial Solutions
3M Center Bldg 220-12E-04
St. Paul, MN 55144

Phone 1-800-328-0033
Web 3M.com/drivethru